

Quick **Start** Guide

Getting Started

This Quick Start Guide explains how to get **P-KEYBOARD™** up and running fast on your **LOKUMA** OSP 200 or 300 Control



- Contact licensing@dataZenEngineering.com for annual license pricing and instructions
- Download the P-KEYBOARD User Guide at dataZenEngineering.com for more detailed information about this APP.

dataZen Engineering
5W Hargett St, Suite 200, Raleigh, NC 27601 USA
Support@dataZenEngineering.com

Step 1

Download P-KEYBOARD from dataZenEngineering.com to a flash drive.



P-KEYBOARD Installer 80MB

Step 2



Insert flash drive into USB port on front of OSP control



- THINC API Version 1.12.1.0 or 1.15.0.0 or 1.17.2.0 must be installed and running
- API icon in screen tray on OSP control must be **green** before continuing



Step 3

- **Launch** Windows Explorer
- **Navigate** to P-KEYBOARD on USB disk drive
- **Click** "P-KEYBOARD Setup" compressed folder
- **Click** "P-KEYBOARD Setup" folder
- **Click** "Setup.exe" to begin the install
- **Click** "Install" for any required items shown on Installation Wizard screen
- **Continue** to follow the installation screen directions to complete the install
(Note: Installation can take several minutes)
- **Click** "Finish" upon completion of installation
- **Recycle** OSP control by pressing the **RED** button  to shut down and then **WHITE** button  to restart
- **Launch** P-KEYBOARD using the quick start icon on the OSP control toolbar after API icon is **green**



Finished